

AIRPORT DIAGRAM

DALLAS-FORT WORTH INTL (DFW)
DALLAS-FORT WORTH, TEXAS

AL-6039 (FAA)

ASDE-X Surveillance System in use.
Pilots should operate transponders
with Mode C on all twys and rwy.

ATIS ARR 123.775
DEP 135.925
DFW TOWER
126.55 127.5 EAST
124.15 134.9 WEST
GND CON
121.65 121.8 EAST
121.85 WEST
CLNC DEL 128.25

Group VI aircraft require advance notice and
follow-me services while taxiing to or from
ramps or runways.

RWY 13L-31R, 13R-31L, 17C-35C, 17L-35R,
17R-35L, 18L-36R, 18R-36L
S-120, D-200, 2S-175, 2D-600,
2D/2D2-850

FIRE STATION No. 3
EAST AIR FREIGHT
FEDERAL EXPRESS

HOLD

HANGAR 5

EAST TWR 783

FIRE STATION No. 1

ELEV 562
ELEV 567
ELEV 524
ELEV 508
ELEV 575
ELEV 562
ELEV 563
ELEV 575
ELEV 577
ELEV 591

13401 X 150
13401 X 200
13400 X 200
13400 X 150
9000 X 200
9300 X 150

NE HOLD PAD
1E CORPORATE AVIATION RAMP
NW HOLD PAD

HOTEL
CENTER TWR 799
U. S. CUSTOMS

SE HOLD PAD
AIRFREIGHT
FIRE STATION NO. 5
CENTRAL TERMINAL AREA
SW HOLD PAD

FIELD ELEV 607
FIRE STATION #2
UPS RAMP

LAHSO
AA
WEST TWR 855
WEST AIR FREIGHT
HANGARS

WEST CARGO
WEST TWR 855

FIRE STATION No. 4
CENTERLINE LIGHTING ON ALL TAXIWAYS

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
REARBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

JANUARY 2010
ANNUAL RATE OF CHANGE
0.1° W

SC-2, 25 AUG 2011 to 22 SEP 2011

SC-2, 25 AUG 2011 to 22 SEP 2011

AIRPORT DIAGRAM

DALLAS-FORT WORTH, TEXAS
DALLAS-FORT WORTH INTL (DFW)